



SPOTLIGHT ACCESSORIES


Colour Change Wheels

Ref. 382, 410, 622

These accessories fulfil the dual functions of a remotely selected colour change unit for stage lighting applications, and also a continuously rotating colour wheel suitable for dance halls and display features.

The disc gives a choice of five colours and the rotary movement results in a cross-fade from one colour to the next.

The assembly slides in the colour frame runners of the spotlight and control is by means of a six-position rotary switch mounted in a control box. This switch selects any one of the five apertures or continuous rotation. A separate set of switch contacts is required for each colour change unit but if continuous rotation only is required then a control box is unnecessary.



Five of the positions of each control switch are numbered and each selects the corresponding aperture at the colour change wheel which rotates until the chosen aperture is brought to rest before the lens of the spotlight. A neon pilot above each switch remains alight while the motor is in operation. The sixth position of the switch, marked C, provides continuous rotation.

All control boxes are fitted with a cartridge fuse and those for four units and above are fitted with a master switch permitting the presetting of individual controls.